

LPR

הגדרת מצלמות LPR של דאוזה



Dahua DHI-ITC215-PW4I-IRLZF27135

[Be the first to review this product](#)

- 1/2.8 inch 2Megapixel Progressive scan CMOS
- WDR, Day/Night(ICR), 3DNR,BLC, HLC
- H.265& H.264 dual-stream encoding
- Micro SD memory
- Powerful 2.7-13.5mm motorized lens and IR light, ideal for monitor ANPR
- IP67, and superior performance for outdoor applications
- Embedded with LPR algorithm inside the camera
- Vehicle data structuring: license plate recognition, vehicle size, vehicle color etc.

[Specifications Document](#)

Availability: **In stock**



ITC237-PU1B-L

2 Megapixel Full HD WDR Access ANPR Camera




ITC952-RU2D-(IR)L EoL

9MP Deep Sense Traffic Camera

- > Adopting high-performance multi-core processor
- > Adopting high-performance image sensor
- > Adopting ISP function
- > Adopting deep-learning intelligent algorithm
- > Multiple signals,data and communicant port
- > Precisely synchronizing signal input & output
- > Innovative and creative on the ITS concept & implementation
- > All-in-one integrated design (trigger detection, behaviour analysis & information recognition)
- > Impeccable low-energy consumption AIO design
- > Build-in HD camera,interface connector,easy to install and debug.



חיבור מגעים להפעלת שער או סירנה



כניסה למצלמה דרך כתובת IP



הגדרת מצלמות LPR



WEB SERVICE v3.0

Live

Playback

Query

Setup

Alarm

Logout

Main Stream

Sub Stream

Protocol TCP

Fluency Default

ANPR Receive

Record Type

day

Zoom and Focus

0Kbps

3840*2160

Obtain Plate Info

Real Plate Info

Index	Event Type	Capture Time	Lane	Plate	Region	Direction	Speed(km/h)	Vehicle Sign	Vehicle Type
-------	------------	--------------	------	-------	--------	-----------	-------------	--------------	--------------

הגדרת מצלמות LPR

WEB SERVICE v3.0

Live

Playback

Query

Setup

ITC

- > Work Mode
- > Lane Property
- > Snapshot
- > Intelligent
- > OSD Config
- > Snap Mosaic
- > Snap Cutout
- > Extra Device

- > Blocklist and Allowlist
- > Pedestrian Traffic Flow
- > Device Direction
- > Intelligence Default

- ▶ Camera
- ▶ Network
- ▶ Event
- ▶ Storage
- ▶ System
- ▶ System Info

Allowlist Setup

Allowlist Search

Blocklist Search

Barrier Control

☒ Enable

☒ Start Match

Care Word

1 2 3 4 5 6 7
☐ ☐ ☒ ☒ ☒ ☒ ☒

MinLength

4

Default

Refresh

Confirm

2

1

3

הגדרת מצלמות LPR

WEB SERVICE v3.0

Live Playback Query Setup

ITC

- > Work Mode
- > Lane Property
- > Snapshot
- > Intelligent
- > OSD C
- > Snap M
- > Snap Cutout
- > Extra Device
- > Blocklist and Allowlist
- > Pedestrian Traffic Flow
- > Device Direction
- > Intelligence Default
- ▶ Camera
- ▶ Network
- ▶ Event
- ▶ Storage
- ▶ System

Allowlist Setup Allowlist Search Blocklist Search **Barrier Control**

☒ Enable

Control Type ☐ AllSnapCar (Camera) ☐ Plate Strobe (Camera) ☒ TrafficAllowlist ☐ Order

Open Config

Relay-out **1** **2**

Signal Duration Sec. (1000~10000)


Default Refresh **Confirm**

Open Test

1

2

3



The diagram illustrates the configuration steps for the LPR camera system. Step 1 points to the 'Barrier Control' tab. Step 2 points to the 'Blocklist and Allowlist' menu item. Step 3 points to the 'Confirm' button. A blue line connects the 'Confirm' button to the barrier gate system.

הגדרת מצלמות LPR

WEB SERVICE v3.0

Live Playback Query Setup Alarm Logout

ITC

- > Work Mode
- > Lane Property
- > Snapshot
- > Intelligent
- > OSD Config
- > Snap Mosaic
- > Snap Cutout
- > Extra Device
- > Blocklist and Allowlist
- > Pedestrian Traffic Flow
- > Device Direction
- > Intelligence Default
- ▶ Camera
- ▶ Network
- ▶ Event
- ▶ Storage
- ▶ System
- ▶ System Info

Allowlist Setup **Allowlist Search** Blocklist Search Barrier Control

Enter Plate No. Find 0 record(s)

Import Allowlist

No.	Plate Number	Vehicle Type	Modify	Delete
-----	--------------	--------------	--------	--------

Detail Info

1

2

3

4

5

Add

Filter Condition

Plate Number

Begin Time

End Time

Detail Info

Plate Color

Vehicle Type

Master of Car

Plate Type

Vehicle Color

☐ Continue Adding

No Record

הגדרת מצלמות LPR

CE-v3.0

Live

Playback

Query

Setup

Alarm

Logout

Allowlist Setup

Allowlist Search

Blocklist Search

Barrier Control

Enter Plate No.

Search

Find 1 record(s)

Import Allowlist

Browse...

Import

No.	Plate Number	Vehicle Type	Modify	Delete
1	1122233	Large Car		

עד 1000 רכבים ברשימה



עריכה



מחיקה

1 / 1

Detail Info

Plate Number:
Plate Color:
Vehicle Type:
End Time:

1122233
Yellow Background Black Text
Large Car
2022-03-07 23:59:59

Master of Car:
Plate Type:
Begin Time:
Vehicle Color:

Avi
War Car
2021-03-08 00:00:00
White

Export

Add

Clear All

הגדרת מצלמות LPR

EV3.0

Allowlist Setup | **Allowlist Search** | Blocklist Search | Barrier Control

Enter Plate No. Find 1 record(s)

Import Allowlist

No	Plate Number	Vehicle Type
1	1122233	Large Car

Detail Info

Plate Number:

Plate Color:

Vehicle Type:

End Time:

Master of Car:

Plate Type:

Begin Time:

Color:

Avi

War Car

2021-03-08 00:00:00

White

Export

Add

Clear All

Encrypt Config


Export Encryption ☐ Open ☒ Close

Warning Exporting without encryption has a security risk. Is it exported?

Confirm

Cancel

Confirm



2

יצוא
לאקסל

TrafficAllowList.CSV - Excel

File Home Insert Page Layout Formulas Data Review View Tell me what you want to do...

Clipboard: Cut, Copy, Paste, Format Painter

Font: Calibri, 11, Bold, Italic, Underline, Text Color, Background Color

Alignment: Wrap Text, Merge & Center

Number: General, Currency, Percentage, Decimals, Fractions

Styles: Normal, Bad, Good, Neutral, Check Cell, Explanatory..., Input, Linked Cell

	A	B	C	D	E	F	G	H	I	J
1	Begin Time	Cancel Time	Master Of Car	Plate Color	Plate Number	Plate Type	Vehicle Color	Vehicle Type		
2	08-03-21 0:00	07-03-22 23:59	Moshe Cohen	1	8489813	3 A		1		
3	08-03-21 0:00	07-03-22 23:59	Avishai Saidi	1	4889457	3 A		1		
4	08-03-21 0:00	07-03-22 23:59	Ronen Zaiger	1	55889999	3 A		1		
5	08-03-21 0:00	07-03-22 23:59	Alex Levi	1	88777554	3 A		1		
6										
7										
8										
9										
10										
11										
12										

Microsoft Excel

Some features in your workbook might be lost if you save it as CSV (Comma delimited). Do you want to keep using that format?

Yes No Help

הגדרת מצלמות LPR

Allowlist Setup | **Allowlist Search** | Blocklist Search | Barrier Control

Enter Plate No. Search Find 1 record(s)

Import Allowlist Browse... Import

No.	Plate Number	Vehicle Type	Modify	Delete
1	1122233	Large Car		

חיפוש של קובץ אקסל לייבוא רשימה

Detail Info

Plate Number: 1122233
Plate Color: Yellow Background
Vehicle Type: Large Car
End Time: 2022-03-07 2

Master of Car: Avi

Export Add Clear All

Allowlist Setup | **Allowlist Search** | Blocklist Search | Barrier Control

Enter Plate No. Search Find 1 record(s)

Import Allowlist TrafficAllowList.CSV Browse... Import


No.	Plate Number	Vehicle Type
1	1122233	Large Car

Encrypt Config

Import Encryption ☐ Open ☒ Close

⚠ Importing without encryption has a security risk. Is it imported?

Cancel Confirm



הגדרת מצלמות LPR

חיפוש
מחדש

Allowlist Setup | **Allowlist Search** | Blocklist Search | Block Control

Enter Plate No. Search Find 4 record(s)

Import Allowlist TrafficAllowList.CSV Browse... Import

No.	Plate Number	Vehicle Type	Modify	Delete
1	1122233	Large Car		
2	2233366	Large Car		
3	55889999	Large Car		
4	88777554	Large Car		

Detail Info

Plate Number: 1122233
Plate Color: Yellow Background Black Text
Vehicle Type: Large Car
End Time: 2022-03-07 23:59:00

Export Add Clear All

Avi
War Car
2021-03-08 00:00:00
White

Modify

Filter Condition

Plate Number 55889999
Begin Time 2021-03-08
End Time 2022-03-07

Detail Info

Plate Color Yellow Background Bla
Vehicle Type Large Car
Master of Car DIDI
Plate Type War Car
Vehicle Color White

Cancel Save

רשימה
הובאה
בהצלחה

מצב שבו כל הרכבים יכנסו ורק אלה
שברשימה השחורה – המחסום לא יעלה

הגדרת מצלמות LPR

כל הרכבים
יכנסו חוץ
מאלה
שברשימה
השחורה

WEB SERVICE v3.0

Live

Playback

Query

Setup

ITC

> Work Mode

> Lane Property

> Snapshot

> Intelligent

> OSD Config

> Snap Mosaic

> Snap Cutout

> Extra Device

> Blocklist and Allowlist

> Pedestrian Traffic Flow

> Device Direction

> Intelligence Default

▶ Camera

▶ Network

▶ Event

▶ Storage

▶ System

▶ System Info

Allowlist Setup

Allowlist Search

Blocklist Search

Barrier Control

☒ Enable

Control Type

☐ AllSnapCar (Camera)

☐ Plate Strobe (Camera)

☒ TrafficAllowlist

☐ Order

Open Test

Open Config

Relay-out

1 2

Signal Duration

1000

Sec. (1000~10000)

Default

Refresh

Confirm

הגדרת מצלמות LPR

WEB SERVICE v3.0

Live

Playback

Query

Setup

ITC

- > Work Mode
- > Lane Property
- > Snapshot
- > Intelligent
- > OSD Config
- > Snap Mosaic
- > Snap Cutout
- > Extra Device
- > Blocklist and Allowlist
- > Pedestrian Traffic Flow
- > Device Direction
- > Intelligence Default
- ▶ Camera
- ▶ Network
- ▶ Event
- ▶ Storage
- ▶ System
- ▶ System Info

Allowlist Setup

Allowlist Search

Blocklist Search

Barrier Control

☐ Enable

Enter No.

Search

Import

Browse...

Import

Plate Number

Vehicle Type

Modify

אותו התהליך
להגדרת
רשימה
השחורה

Detail Info

Export

Add

Clear All